


Help Kit


Unit: mm, Scale 1 : 1



XSHK


Screw Remover

L	Art. No.
25	XRFS 2 S
33	XRFS 2




Screw Tap Repair

Type	Art. No.
Tap	XRSTR
11° Guide	XRSG 11




Fixture Remover

Type	Art. No.
Remover Screw	XRFSS
Screw Driver	XRFSD
Remover	XRFST




Abutment Hex Remover

L	Art. No.
20	XRHR 20
25	XRHR 25



Cover & Abutment Screw Remover

L	Art. No.
25	XRRHDE



Wrench

Scale 1:0.7

XRFRW

